



3DGence | Przyszowice Office | Graniczna 66, 44-178 Przyszowice, Poland
www.3dgence.com

Recommendations for printing from ULTEM AM9085F-1010 [Sabic]

The material should be dried before printing to remove any moisture that the material has absorbed. After unpacking from the box, it is recommended to dry the material at temperature 120°C for approx. 24 hours. You can use the 3DGence INDUSTRY F420 working chamber or a dedicated dryer for this purpose.