



3DGence | Przyszowice Office | Graniczna 66, 44-178 Przyszowice, Poland
www.3dgence.com

Recommendations for printing from PA6 material [3DGence]

Before printing the material should be dried at temperature 85°C for a minimum 24h. Before printing, one layer of specimen Magigoo PA or one layer of Dimafix should be applied to the heatbed. After printing, wait until the device cools down, and then remove the model from the heatbed. It is recommended to use pliers for removing supports, wear gloves and eye protection glasses.